



ELECTRO-MOTIVE DIVISION • GENERAL MOTORS CORPORATION
MAINTENANCE INSTRUCTION

AIR COMPRESSOR MODELS WBO AND WBG

DISCHARGE VALVES

All compressors that are run at speeds exceeding 900 RPM are equipped with nine spring discharge valves, Fig. S-1. The configuration of the valve bumper and seat is somewhat different than the six spring valve shown in Fig. 9 of M.I. 1144. The inner disc is still held by three springs but the outer disc now has six springs holding it against the seat.


The springs in the nine spring valve have a Teflon coated button and must be replaced with the same kind when replacement is necessary. Maintenance procedures and rebuild specifications are the same as those given for the six spring valves.

The six and nine spring valves are interchangeable in any water cooled compressor. However, the six

spring valve can not be used in any compressor running at speeds exceeding 900 RPM.


LUBE OIL INLET VALVE

Current compressors are equipped with a new disc type lube oil inlet valve, Fig. S-2, which provides improved oil flow. This inlet valve is directly interchangeable with the ball bearing type inlet valve. The disc type valve must be used on compressors which are to run in excess of 900 RPM and is also recommended for use in older direct feed compressors when replacement is necessary. When a defective inlet valve is found, the valve must be replaced as an assembly.



16226

Fig. S-1 — Nine Spring Discharge Valve



16227


Fig. S-2 — Lube Oil Inlet Valve

This Supplement should be inserted in all copies of M.I. 1144.

INTERCOOLER

The water cooled intercooler provided on compressors to be run in excess of 900 RPM is a two pass intercooler, Fig. S-3. The compressed air passes through the intercooler from the low pressure cylinder to the high pressure cylinder, the same as it does in a single pass intercooler. However, the two pass intercooler has two water inlet and two water outlet lines. The additional cooling water flow provides increased cooling for the compressed air between the low pressure and high pressure stages.

Maintenance procedures are the same for the two pass intercooler as for the single pass intercooler described on pages 5 and 6 of M.I. 1144.



16228

Fig. S-3 – WBO Air Compressor With
Two Pass Intercooler



MAINTENANCE INSTRUCTION

AIR COMPRESSOR MODELS WBO AND WBG

This M.I. covers the WBO and WBG air compressors used on locomotives shipped since January 1, 1969 and provides instructions for upgrading older versions of these two models. It DOES NOT SUPERSEDE M.I. 1110 Rev. A which covers compressor Models WXO, WXE, WXG, ABO, ADJ, and ADX.

DESCRIPTION


The WBO and WBG model air compressors, Fig. 1, are water cooled, two stage air compressors. Each compressor has its own oil pump and pressure lubricating system. Both models are equipped with a deep sump crankcase.

The WBO compressor has two low pressure and one high pressure cylinders and the WBG compressor has four low pressure and two high pressure cylinders. The low pressure cylinders are set at an angle to the vertical high pressure cylinder

position. The pistons of the high and low pressure cylinders are all driven by a common crankshaft.


The air is cleaned before it enters the compressor by passing through a dry type air filter mounted on the air inlet manifold on the WBO compressor. On the WBG compressor an air inlet filter is mounted directly to each of the two low pressure cylinder heads.

Air from the low pressure cylinders goes to a water cooled intercooler to be cooled before entering the high pressure cylinder.



WBO

15478



WBG

15696

Fig. 1 — Air Compressor




Fig. 2 — Lubricating System

LUBRICATING SYSTEM

The lubricating system is shown in Fig. 2. The crankshaft is rifle drilled for the passage of oil to the connecting rod bearings. A plunger or piston type lubricating oil pump is actuated by a strap riding on an eccentric on the crankshaft. Oil under pressure from the pump flows through the drilled pump plunger and eccentric into the drilled passages of the crankshaft. These passages supply oil to the precision type connecting rod bearings. The piston pin bearings and crankshaft main bearings are lubricated by oil mist from the connecting rod oil throw-off.

The relief valve block mounted on the side of the crankcase houses the relief valve,




Fig. 3 — Oil Pressure Relief Valve

Fig. 3, which is used to control the oil pressure. A plugged opening is provided for application of a pressure gauge for test purposes only.

Oil level is determined on current air compressors by a float gauge.

OPERATION

In the two-stage compressors, air at atmospheric pressure is drawn in through the filter and intake valve into the low pressure cylinders, during the downward stroke of the piston. As the air is compressed on the upward stroke, the intake valve is closed and the air at higher pressure is forced through the discharge valve into the intercooler. Air leaves the intercooler, entering the high pressure cylinder through its intake valve. As the high pressure piston moves upward, it compresses the air to a higher pressure, forcing it out through the discharge valve and connecting piping to the main air reservoir.

Since each compressor is driven by the engine, the compressor is running whenever the engine is running, although not continuously pumping air.

When the main reservoir air reaches the recommended pressure, the compressor governor control admits air to the unloader assembly cutting out the compressor action by holding the intake valve open. When the reservoir pressure falls, the air operating the unloader is cut off, the intake valve is released, and the compressor resumes normal pumping.

CRANKCASE BREATHERS

The WBO models are equipped with a crankcase breather which permits a partial vacuum in the compressor crankcase. To accomplish this, the breather acts as a check valve. When pressure builds up in the crankcase as the pistons move down, the breather valve opens.

As the pistons start up, the valve closes preventing the admission of air into the crankcase.

The breather, Fig. 4, is connected to the compressor air intake manifold. This prevents vapors escaping into the air around the compressor. There should be only a slight spring tension on the spring-backed valves. This will cause abnormal pulsation at the breather as the pistons move up and down, nullifying the purpose of the breather.

The breather should be cleaned periodically with petroleum solvent and blown dry with compressed air.




Fig. 4 — Crankcase Breather

MAINTENANCE

LUBRICATION

It is important that the compressor crankcase oil be changed at intervals given in the applicable Scheduled Maintenance Program. After draining the oil, clean the inside of the crankcase by flushing with petroleum solvent and wipe clean with lint free bound edge towels. For compressor lubricating oil specifications refer to

Locomotive Service Manual. See Maintenance Data page for the correct crankcase oil capacity.

Oil in the crankcase should be maintained at a sufficient level to keep the oil level float gauge needle in the green "RUN" area. Oil level can be determined at anytime, with compressor running or stopped, with a float gauge. It is not necessary to add oil until the oil level float gauge needle enters the red area.

A plugged pipe opening is provided in the oil relief valve body for application of pressure gauge 8127030 to check compressor oil pressure. After checking pressure, the gauge should be removed and the pipe opening again plugged.

Oil pressure should be checked periodically to ensure that the pump and associated parts are functioning properly. Oil pressure at 140° F. oil temperature should be 15-20 psi. Oil pressure is varied by adding or removing shims under the pressure adjusting screw on the constant pressure relief valve, Fig. 3. This valve provides for correct minimum oil pressure at idling speed and ensures adequate oil pressure at all speeds.

Since variations in operating conditions such as ambient temperature and length of time a compressor is loaded can influence the performance of individual compressor oils, a final selection of a particular brand to be used is best made by testing under actual operating conditions. The oil should be tested for at least three months, and preferably six months, to be sure the variables of operation are encountered. A compressor in new condition in respect to cylinders, rings, heads, and bearings should be selected for the test.

At the end of the test period, the compressor and the air system of the locomotive

should be inspected. In the compressor, the piston pin bushings, piston rings, cylinder walls and pistons should be inspected for lacquer deposits. Discharge valves should also be inspected for lacquer and hard or soft carbon deposits. The locomotive air system can be qualified for lacquer accumulation by examination of the magnet valves, brake valves, and feed valves. The presence of any lacquer, or hard carbon or excessive deposits of soft carbon indicates an unsuitable lubricant.

The presence of an oily substance in a feed valve does not necessarily mean an oil pumping air compressor, but may mean an unsuitable oil is being used. There are unstable ends in some oils which will distill off and deposit as an oil formation at expansion areas such as feed valves. Generally speaking, this substance will lacquer a shiny surface rapidly.

Heavy detergent oils will form hard lacquer deposits in the cylinder heads and on the cylinder walls which will result in oil carryover in the system. Heavy weight oils will cause excessive wear in the piston pin bearings. Detergent or high film strength oils would probably improve piston pin bearing life, but cannot be used

because ring seating is affected and carry-over into the air system has a detrimental effect on air brake equipment.

Extensive experience has definitely led to the conclusion that heavy detergent oils or mineral oils with unstable ends will not satisfactorily lubricate compressors. In several instances of compressor failures, examination of failed parts has shown that failure resulted from use of unsuitable oils. This has been confirmed by the fact that changing to an oil suited to the application has eliminated compressor failures as a problem.



ORIFICE TESTING

The compressor should be given an orifice test, as a measure of its condition, at intervals as outlined in the D.O.T. rulings.

The graphs shown in Fig. 5 indicate the recommended limits for the compressors covered by this instruction. For part numbers of various size orifices and adapters for these tests, refer to the Service Tools Catalog.

AIR FILTERS

The air inlet filter or filters should be changed at intervals given in the applicable



15698

Fig. 5 — Compressor Orifice Test Limits

Scheduled Maintenance Program, or more frequently if operating conditions require.

For a detailed explanation of the filters and the correct replacement elements required, see the applicable Locomotive Service Manual.

DISASSEMBLY

Before the compressor is disassembled, the exterior of the unit should be thoroughly cleaned and the parts marked to ensure that when reapplied, such parts will be returned to their original location. Care should be taken when handling parts so as not to damage otherwise undamaged parts. When cleaning the parts, do not put main bearings, crankshaft, connecting rods, valve, pistons or piston pins in same basket with other compressor parts.

Cylinder heads, cylinders, crankcases, end plates, handhole covers, suction and discharge elbows, manifolds, and cast iron intercoolers should be placed in a cleaning solution and left there a sufficient length of time to ensure proper cleaning. After removal from the cleaning solution, these parts should be wire brushed and magnaflux inspected for defects.

The pistons, crankshaft, and connecting rods should be thoroughly cleaned (do not wire brush) and magnaflux inspected for defects.

After magnaflux, all parts should be re-washed and de-magnetized before re-assembly.

1. Remove pipe plug at bottom of crankcase to drain lube oil. Drain compressor cooling water by draining locomotive system.
2. Remove all piping assemblies and both handhole covers.

3. Remove air filter, air intake manifold, crankcase breather, oil pressure relief valve, safety valve, and suction and discharge elbows.

4. Remove intercooler assembly.

5. Remove cylinder heads and cylinder assemblies.

6. Remove connecting rod cap bolts and pull piston and connecting rod assemblies off of crankshaft.

7. Remove the oil pump and oil pump eccentric from crankcase.

8. Remove end plate bolts and pull end plates off the crankshaft.

9. Remove crankshaft from crankcase.

10. Individual assemblies can now be disassembled by following instructions covering the particular assembly.

INTERCOOLER

CLEANING

It is recommended that the intercoolers be removed at overhaul time and cleaned inside and out. Oil film inside the intercooler, or an accumulation of dirt, will materially reduce its efficiency with the possibility of excess moisture being carried into the locomotive air system.

The intercoolers should be cleaned using an inhibited alkaline or solvent cleaner and water. After cleaning, flush thoroughly with hot water, and blow dry.

SAFETY VALVE TEST AND ADJUSTMENT

Safety valves, Fig. 6, are provided to relieve excessive pressure buildup in the

intercooler. These valves are tested and adjusted as follows:

Test Procedure

In testing the safety valves, Fig. 6, it is essential that the air supply be adequate (at least 20,000 cu. in. reservoir) with piping to the valve not less than the size of the pipe thread fitting on the end of the valve. If restricted feed is used, the restriction must not be less than 7/16" in diameter. If air supply is not adequate, the valve cannot be set properly.

The valves must not lift before the specified lift pressure and the blowdown of the valve must not exceed 10 pounds pressure. The valve must be fully assembled when the test is made.

The valves should lift at a static air pressure between 64 and 66 psi.

Adjustment

A valve which does not lift or reseat within the specified pressure ranges should be disassembled and thoroughly cleaned with a solvent or caustic cleaner. (Do not use a wire brush.) Replace any damaged parts.




Fig. 6 — Intercooler Safety Device

Reassemble the valve with a small amount of light oil between the valve disc and the valve body. Apply a mixture of light oil and graphite on the lever pivot and lift pin.

Adjust the lift and reseating pressures of the valve to those given under Test Procedure. Adjust the lift pressure by adjusting the pressure screw to change spring tension on the disc. Adjust the reseating pressure by loosening the regulator ring set screw and adjusting the regulator ring. After the adjustments have been made, the setscrew and the locknut should be lockwired and sealed.

COMPRESSOR UNLOADER VALVES

The piston type unloader valves, similar to Fig. 7, are used on the compressor to hold the intake or suction valves off their




Fig. 7 — Piston Type Compressor Unloader Valve

seats to stop compressor pumping when the main reservoir air is at the proper pressure.

Disassemble and service the valves as follows:

1. Remove the unloader valve assembly and disassemble the cylinder head, or cap and gasket.
2. Remove the piston assembly from the cylinder.
3. Clean the piston and ring. Check that the ring operates freely in its groove.
4. Clean and inspect the interior of the unloaded cylinder.
5. Apply a small amount of fine lapping compound to the angle seat on the piston. Insert the piston in the cylinder and lap the angle seats of the piston and housing.
6. After lapping the seats, remove the piston and clean both piston and housing of any compound.
7. Apply some light grease comparable to petroleum jelly to the cylinder, piston, and ring and reassemble the parts using a new gasket under the cylinder cap.

DISCHARGE AND SUCTION VALVES

Each cylinder has one discharge valve, Fig. 8, and one suction valve, Fig. 9. Each valve is mounted in a cage-like assembly. Concentric flat ring valve discs are installed between the bumper and the seat. Three springs hold each disc against its seat. Springs are helical design replacing prior used conical springs. The valve assembly is held together by a cap bolt. The spring bears against the valve disc itself. In the discharge valve assembly the springs are above the discs holding




Fig. 8 — Discharge Valve Assembly




Fig. 9 — Suction Valve Assembly

the discs down against their seat, while on the suction valve assembly the springs are below the discs, holding them up against their seats.

Special valve holders are available that facilitate air compressor valve maintenance. These valve holders ensure proper rigidity while working on the valves, and eliminate possible damage to the assembly. See Maintenance Data at the end of this instruction for the correct part number.

REMOVING DISCHARGE VALVES

1. Back off the crown nut in the center of the cover plate and unscrew the hexagon socket set screw several turns.

2. Remove the cover plate nuts and remove the plate.
3. After removing the valve clamp, the valve assembly can be removed.
4. Cover the valve openings after valve removal to prevent anything from falling into the cylinder.

REMOVING SUCTION VALVES

On the low pressure suction valve, after removing the cover plate nuts, the unloader and clamp are removed as an assembly. The valve can then be removed.

On the high pressure suction valve, after removing the cover plate nuts, the cover and unloader assembly are removed as an assembly. The clamp is first removed to permit valve removal. After removal of the cover, observe the screws which hold the clamp, and loosen them several turns.

SUCTION AND DISCHARGE VALVE DISASSEMBLY

The valve can be taken apart to remove the springs and valve discs by removing the nut and lockwasher or the cap bolt. The valve parts should then be thoroughly cleaned.

VALVE RECONDITIONING

Valve Discs

The valve discs should be replaced if worn enough to form a step. The following information is provided to qualify a disc for reuse.

A valve disc that does not show any defects and requires only cleaning should not be lapped or ground.

If a disc must be lapped to remove some minor defects, even pressure should be placed on the disc. The valve disc should not be pressed with the fingers, as the

pressure will be applied only on small areas. A disc can be sprung enough with finger pressure to cause a wavy finish that will allow the valve to leak.

The disc should be placed in a holder that will distribute the pressure evenly while lapping. A simple holder can be made from a flat steel plate cut out to a depth of about 2/3 the thickness of a disc.

The disc should not be lapped to its seat. If the disc is not perfectly flat, the seat will be given a wavy surface. The disc should be lapped on a perfectly flat lapping plate. The lapping compound should be very fine so as to put an almost mirror finish on the disc.

Occasionally, a valve disc which has had a long period of service will stop rotating. If the disc remaining in one position long enough, the valve springs will wear rings in the disc. Discs in this condition should be discarded. The rings, if deep enough, are weak spots that can develop into cracks. Also, a valve disc which has had considerable service may have a wear step in it. A disc in this condition should be discarded. Minimum valve disc thickness should not be less than that stated in the Maintenance Data.

Valve Seats

Valve seats must be completely free of any nicks and the edges should be square and sharp. If a valve seat requires lapping. It should be lapped to a master plate using a fine compound that will give a shiny, scratch free surface.

While inspecting valve seats refer to dimensions in the Maintenance Data.

Valve Bumper

Inspect valve bumper for cracks or excessively worn areas. See the Maintenance Data for dimensions.

Valve Springs

New valve springs should be used when reconditioning valves. Valve springs should have a slip fit in the bumper holes, just tight enough so that they do not fall out when the bumper is held upside down. If the springs are too tight, they may not set square and will bind.

Cleaning

After reconditioning and inspection, all valve parts should be thoroughly cleaned for reassembly.

VALVE REASSEMBLY

Discharge Valve

Any discharge valves held in place with a stud and nut should have the stud replaced with a cap bolt. This will eliminate removing the stud each time a valve is lapped.

1. Hold bumper assembly in one hand with spring pockets facing up.
2. Place springs in place, with large diameter inserted into spring pocket, and place inner and outer valve discs on their respective springs.
3. Invert the seat assembly and position it on the discs.
4. Hold this assembly together and apply the cap bolt and tighten to 50-60 ft-lbs. torque.

Suction Valve

1. Hold the bumper assembly, spring pockets up, and place the inner and outer valve disc springs in their pockets.
2. Place the respective discs on their springs.
3. Carefully place the seat assembly over the discs.

4. Apply the cap bolt and tighten to 50-60 ft-lbs torque.

Using a blunt-nosed piece of wood inserted through the valve opening, check that the valve discs are free to move. Check for leaks by filling valve pockets with fuel oil.

If valve assemblies are not to be used immediately, they should be oiled and wrapped to keep them clean. If the valves are to be stored, they should be protected against rust.

CRANKSHAFT

CLEANING

If the crankshaft is removed for any reason, it should be given a thorough cleaning with solvent, particularly during any overhaul work, since metallic particles may lodge in the oil passages. Therefore, all rifle drillings must be cleaned of every particle of grit.

The main drilling of the crankshaft consists of two intersecting passages. One of these passages is parallel to the crankpin and is plugged at both ends. These plugs are provided to aid in cleaning and must be removed. A long-handled bristle brush having slightly over a 5/16" diameter is recommended for cleaning passages. During scrubbing, solvent should be directed into the passages under approximately 25 psi pressure. Washing and brushing must be repeated until the oil passages and crankshaft are absolutely clean. After cleaning, be sure to replace the passage plugs which were removed.

INSPECTION

The main bearing surfaces of the crankshaft should not receive any wear and should not be less than 3.376" diameter. The oil pump eccentric surface should not be scored, tapered, or out-of-round in excess of .0005". The runout of the

crankshaft should not exceed .010" at the main bearing journal, with the crankshaft located in centers.

The crankpin on the crankshaft should not be more than .0015" out-of-round, or worn to less than 3.496" diameter. If it is damaged, or worn beyond above limits, it can be reconditioned by grinding, provided the surface will clean up to .030" undersize.

If the crankshaft has grooved seal surfaces, use synthetic oil seal kit 8367712 at the oil pump end and kit 8367711 at the opposite end. These kits include a renewable wear sleeve which is to be pressed over the crankshaft to provide an optimum seal riding surface on the crankshaft. Also included is a synthetic oil seal to operate with the 1/8" oversize shaft, provided by the wear sleeve.

1. To apply wear sleeve, the shaft must be clean and seating surface must measure $3.250" \pm .0015"$.
2. Shaft surface must be coated with a liquid sealant or gasket cement.
3. Wear sleeve must be pressed into correct position with arbor or flat plate against sleeve end. Do not hammer on thin edge of sleeve or wear sleeve may become warped or out of round.
4. Remove excess sealant. None should be left on finished working surface.
5. Fill the cavity between the two seal lips with a good quality grease.
6. Install the seal with the name and number side or the lip side facing the outside of the compressor.

All used crankshafts will have some damage in the seal area and it will be advantageous to use the kit, as no crankshaft rework will be necessary in the seal area.

CONNECTING RODS

Connecting rods used in the compressors are equipped with precision bearing inserts. The bearing inserts should be replaced at the time of overhaul or any time their condition warrants replacement.

The connecting rods and bearing shells should be fitted to the crankshaft before the crankshaft is installed in the crankcase. Clearance limits are given in the Maintenance Data at the end of this publication. The connecting rod bearing to crankshaft journal clearance can be checked by the use of plastigage strips.

CYLINDERS

CLEANING AND INSPECTION

The cylinder should be thoroughly cleaned after removal, prior to any inspection or reconditioning. Examine the cylinder for score marks or ridges at the end of the ring travel surface. Inspect cylinders for a maximum out-of-round condition of .001". Also check cylinder diameter to ensure correct clearances may be obtained with the correct size piston.

Accumulated cylinder and piston wear will increase piston to cylinder clearance which is a limiting factor at the time of reapplication. No cylinder should be matched with a new or used piston with a piston to cylinder clearance exceeding the limit given in the Maintenance Data at the rear of this publication.

For example, with a WBO low pressure cylinder worn to a maximum diameter of 7.8795" a piston not less than 7.8710" diameter must be used. Obviously, with a cylinder worn to this diameter the minimum diameter shown in the specifications for a rebuild piston can not be used since the maximum clearance of .0085" would

be exceeded. If cylinders are worn excessively, they should be rebored to oversize increments of .010". It has been found to be more economical to rebores them to .010", .020", or .030" oversize. If cylinders are worn to the extent where they would require more than .030" reboring, it is far more satisfactory and economical to replace them with new cylinders or those rebored to the regular oversizes.

REBORING

When reboring is necessary the cylinders should not be rebored to their final size. They should be rebored to .002" to .003" under their final size to allow enough stock for proper honing. If less stock is left, the boring marks will not be completely removed when the cylinder is honed to size.

HONING

After reboring, the cylinders should be honed for the final finish. A honed finish of 15-30 microinches is desired, with a crosshatch of 25° to 35°. The 15-30 microinch finish can be obtained from stones ranging from 180 to 280 grit. See the equipment list at the rear of this publication for the proper cylinder liner honing set.

Fig. 10 shows pictures of a cylinder wall at various stages of the cylinder reconditioning operation. Figs. 10a and 10b are views of a cylinder after boring and before honing. Notice the rough finish left by the boring tool. New piston rings installed in a cylinder with this finish would be ineffective. Oil consumption and blow-by would remain high because the rings could not form a good seal. Fig. 10c is the same cylinder after 25 strokes with a spring loaded hone. Although honing marks are visible, the boring marks can also be seen. This


finish is still too rough for piston ring seating. Fig. 10d is the cylinder wall after the cylinder was honed to size with a rigid hone. The boring marks have been cleaned up and the cross hatch pattern left by the hone is all that is visible. This surface is ideal for early piston ring seating.

The tolerance allowed on finishing oversize rebored cylinders is +.001" -.000". This tolerance is added to the amount that the cylinder is rebored. For example, if a standard 7.000" cylinder is rebored .010" oversize, the finished diameter after honing should be 7.010"-7.011".


Honing of cylinders at regular maintenance periods should be avoided, except when used to remove scoring. A better practice is to remove any ridge at the top of the ring travel by scraping, and then rough the cylinder by hand using a No. 180 emery cloth to produce a crosshatch pattern at an angle of 25°-35° to the bore.

Of all the operations in repairing an air compressor, cleaning the cylinders may be the most costly one to forget. If the cylinders are not properly cleaned after they are honed, the compressor will wear out in an alarmingly short time. The tiny particles left by the hone will attack the rings, cylinders and any other moving parts in the compressor. Thus, the omission of one procedure can eliminate all the good done by hours of labor and valuable replacement parts. To make certain that the overhaul will last, the following cleaning procedure must be used:


1. Wash cylinder with soap and hot water using stiff fiber brush to clean cylinder bore and flanges thoroughly.
2. Swab each cylinder thoroughly with a clean rag dipped in 10W engine oil.
3. Wipe out cylinder with dry clean cloth.




(a) Highly magnified view of bored cylinder reveals rough finish.



(b) Close-up view of cylinder surface after boring.



(c) Cylinder wall after 25 strokes with flexible hone. Note boring marks.



(d) Proper honing leaves cross-hatch pattern.

12520

Fig. 10 — Cylinder Wall Honing

- Repeat Steps 2 and 3 until clean white cloth can be rubbed on cylinder wall with no stain appearing on the cloth. It is important to use oil for this cleaning procedure because the oil pulls the abrasive particles out of the tiny pores and crevices in the cylinder wall. Solvents will not remove all abrasive particles.

PISTONS

At the time of the compressor overhaul, the pistons should be removed, cleaned and inspected for excess wear. Match the pistons with a new or used cylinder so the diameters result in a piston to cylinder clearance which does not exceed the limit given in the Maintenance Data at the rear of this publication.

Piston ring grooves must be square and free from wear ridges. Clearance between the ring side and groove should not exceed .004", where applicable. Minor scuff marks or scratches can be smoothed or rounded with a file. (Do not use a stone or emery cloth.) All pistons that are to be used again should be given a phosphate treatment as outlined in Maintenance Instruction 1758.

PISTON PIN BEARING REPLACEMENT

Current model compressors are equipped with a prefinished bushing in the low pressure piston assembly and roller bearings, Fig. 11, in the high pressure piston assembly. The roller bearing type piston assembly requires a different piston pin and connecting rod than piston assemblies using other type bushings or bearings.

Low Pressure Piston

When reconditioning machines, replace the low pressure piston pin bushings with the same type that was removed.




Fig. 11 — Piston Pin Roller Bearing Assembly

The old bushings or bearings should be pressed out using driving tool 8231757, Fig. 12. Alternate methods tend to gouge the inside of piston bosses and destroy the piston for further use.

Before attempting to replace the piston bushings, check the piston to see that it is sound and free from excessive scuff marks or wear at the following points:

- Piston ring grooves must be square and free from wear ridges. Clearance between ring side and groove should not exceed .004", where applicable.
- Piston to cylinder clearance must be within condemning limits.
- Minor scuff marks or scratches can be smoothed or rounded with a file. (Do not use stone or emery cloth.)

New bushings should be applied by shrinking the bushing with dry ice or liquid nitrogen and heating the piston. The use of liquid nitrogen will permit dropping





Fig. 12 — Piston Bushing Removal Tool

bushing into piston at room temperature. The use of dry ice will require heating piston to 200° to 300° F. Bushing should be dropped into outside opening of piston boss with inner end of boss squarely seated on piston bushing anvil 8231756, Fig. 13.



12698

Fig. 13 - Installing Piston Pin Bushing

High Pressure Piston


When replacing high pressure piston pin bearings, use roller bearing assemblies, Fig. 11. Those machines which did not previously have roller bearing assemblies will require a different piston, piston pin, and connecting rod.

The old bearings should be removed by pressing to the center of the piston with a 2-1/32" diameter driving tool. Use care not to gouge the inside of the piston bosses with the driving tool.

A piston boss support anvil and plug for pressing in the roller bearings can be made as shown in Fig. 14.

Before attempting to replace the piston bearings, check the piston to see that it is sound and free from excessive scuff marks or wear at the following points:

1. Piston ring grooves must be square and free from wear ridges. Clearance



15702

Fig. 14 - Piston Boss Support Anvil

- between ring side and groove should not exceed .004", where applicable.
2. Piston to cylinder clearance must be within condemning limits.
 3. Minor scuff marks or scratches can be smoothed or rounded with a file. (Do not use stone or emery cloth.)
 4. Wash piston thoroughly to remove any foreign material, then blow it dry with clean, dry air.
 5. Install inner retainer rings in piston pin boss using internal pliers.
 6. Place piston over anvil, Fig. 15, locating piston pin boss approximately in the center of the three countersunk screws in the top of the anvil.
 7. Place roller bearing on plug and start bearing into piston pin bore being sure bearing is parallel with pin bore.
 8. Press bearing into piston until plug bottoms on the O.D. of the piston. Do not over press plug.




Fig. 15 — Roller Bearing Installation

15703

9. Remove plug, rotate piston 180° and relocate the other piston pin boss on the anvil. Repeat Steps 7 and 8.
10. After both bearings have been installed, remove the piston from anvil and install the two outer retainer rings.
11. Cover both ends of the piston pin bore to keep foreign material out of the bearings until the piston pin is installed.

PISTON PIN REPLACEMENT

The piston pin must be replaced if it is scored, defaced, or exceeds clearance limits as given in the Maintenance Data. A special tool is available for piston pin and connecting rod assembly, Fig. 16. This assembly fixture 8213878 ensures proper alignment of the piston pin and connecting rod and prevents twisting the connecting rod when torquing the retaining bolt to the recommended 80-100 ft-lbs. It also positions the rod eye with the slot machined in the wrist pin for application of the retaining bolt.

Connecting rod spreader 8214312, also shown in Fig. 16, is used to expand the wrist pin bore of the connecting rod so it




Fig. 16 — Piston Assembly Fixture And Rod Spreader

8498

may be aligned in the piston assembly fixture without the use of force, which might damage the assembly.

PISTON RINGS

To aid in piston ring identification and location, the various ring combinations for the compressor are shown in Fig. 17. Compression rings are marked on top with a pip or dimple to ensure proper application. Oil control rings are not marked as they may be applied with either side up.

Particular notice should be made of the ring and spring combination used in the low pressure cylinder. This spring and ring combination is applied to the top and No. 2 ring grooves of the piston, with the spring above the ring.

NOTE: Ring side clearance limits given in the specifications do not apply

to the spring and ring combination. Oil control rings are used in the bottom piston ring groove of all compressor pistons.

To properly apply the piston rings, use the correct ring expanding installing tool according to the piston diameter. See the Maintenance Data for the correct ring expanders.

Standard size rings should be used on all standard pistons for all bore sizes up to where a .010" oversize piston can be used. Piston rings should be fitted through the bottom of the cylinders rather than through the top, because the bottom of the cylinder is chamfered to prevent damage to the ring on entry, and this end wears less than the top. Therefore, rings must have at least minimum clearance at the lower end of the cylinders. Piston rings should never be filed to obtain end clearance.

OIL PUMP


The oil pump should fit the crankshaft to the limits listed under Maintenance Data. If the clearance limit is exceeded, a new oil pump eccentric will be required. The oil pump plunger should be inspected for scoring and excessive wear. If the clearance limit is exceeded as given in the Maintenance Data, a new pump assembly should be installed.

OIL PRESSURE RELIEF VALVE

The oil pressure relief valve should be completely disassembled and thoroughly cleaned. All passages should be blown out, using compressed air. The valve should then be reassembled and reset as described in the Lubricating System section.

PRESSURE GAUGES

The orifice screw should be removed and the air and oil pressure gauges tested on



15704

Fig. 17 — Piston Ring Assembly

a dead weight tester. After testing, an orifice screw having an orifice diameter not greater than .015" must be installed in the gauge and staked securely in place.

ASSEMBLY OF AIR COMPRESSORS

The air compressors should be assembled with new gaskets and oil seals. The bearing surfaces of the crankshaft, main bearings, connecting rod bearings, wrist pins, and cylinders should be adequately lubricated with approved air compressor oil, as recommended in Maintenance Instruction 1756.

The area of the crankshaft that the lip of the synthetic rubber seal touches should be well oiled or greased.

1. Install the oil seals in the end plates as explained in the "Crankshaft" section of this publication.
2. Mount the main bearing inner races on the crankshaft and the outer races in the crankcase end plates. The races must be flat against the locating shoulder within .002".
3. Install the crankshaft in the crankcase with a gasket behind the end plate opposite the intercooler and shims at the intercooler so the oil pocket and passage is up, providing gravity feed lubrication to the main bearings.

NOTE: Use oil seal guide 8219901 when sliding the leather type oil seals over the shaft keyway and shoulder on the shaft. Any burr will destroy the feather edge of the oil seal.

4. Check the end thrust of the crankshaft by exerting 250 psi pressure alternately at each end of the shaft and checking shaft movement with a dial indicator. Thrust clearance should not exceed the limits given in the Maintenance Data. If necessary the

end thrust may be adjusted by the addition or removal of shims between the end plate and crankcase.

5. Install the oil pump and oil pump eccentric in the crankcase. Torque the eccentric strap bolts to 35-45 ft-lbs. Install cotter pins in the strap bolts and lockwire the oil pump mounting bolts.

NOTE: The identifying or matching marks on the connecting rods, connecting rod caps, and both halves of the oil pump eccentric must all be on the same side.

6. Install the previously assembled piston and connecting rod assembly on crankshaft. Torque connecting rod bolts to 140-160 ft-lbs. Install locknut hand tight against connecting rod nut and tighten 1/3 to 1/2 turns.

NOTE: When installing the cylinders, cylinder heads and intercooler to the compressor, be sure to use the proper gaskets and initially tighten the bolts hand tight. To limit the cylinder distortion to a minimum the mounting bolts should be tightened to the proper torque value as specified in the Maintenance Data in the following order:

Intercooler to cylinder head.
Cylinder head to cylinder.
Cylinder to crankcase.

7. Using a piston ring compressor, mount the cylinders on the crankcase.
8. The following steps should be taken before installing the cylinder heads to the cylinders to ensure maximum operating performance of the cylinder head gaskets.
 - a. Gasket surfaces on cylinder and heads must be free of deep scratches

and foreign material. The faces of the water cooled heads must be flat within .002".

- b. Gaskets should be dipped in or coated with light motor oil prior to application, to permit flow of gasket and complete sealing. Use of heavy grease, gasket cements or graphite coatings should be avoided as they impair gasket performance and life. Proper positioning of gasket should be attained by using short studs inserted in head before application.
9. The valve covers on the discharge valves, and the unloader on the high pressure suction valves should be installed with the valve clamp screws released. After the covers are installed, the valve clampscrews should be tightened and locked in place with the clamp screw crown nut. On the low pressure suction unloader assemblies, care should be exercised to ensure that the suction valve cover gasket is compressed. If the gasket does not compress, two gaskets should be applied. Do not remove the valve seat gasket.
 10. Mount the cylinder head assemblies containing the suction and discharge valves, onto the cylinders.
 11. Install the intercooler, then tighten the intercooler, cylinder head, and cylinder mounting bolts as explained in Step 7. Tighten cylinder head bolts to 120-130 ft-lbs following the pattern in Fig. 18.
 12. Install the safety valve, suction and discharge elbows, air filter, crankcase breather, and oil pressure relief valve in their proper locations.
 13. If the unloader piping is in good condition, it should be reused. If new




Fig. 18 — Cylinder Head Tightening Sequence

unloader piping is required, the latest type should be used. The piping should be soap tested for leaks at 90 psi.

14. Wipe the crankcase clean with lint free rags and install the handhole covers. If the oil gauge and oil filler were removed from the handhole cover, replace them in their proper position.

COMPRESSOR BREAK-IN AND TESTING AFTER OVERHAUL

Where a customer has many air compressors to break-in and test, it is recommended that a test stand be set up. Drawings covering such an installation will be furnished on request. File Drawing No. 343 covers a schematic piping diagram for an air compressor test stand, and File Drawing No. 603, an air compressor test stand arrangement. If access to a compressor test stand is not possible, the compressor may be tested on the locomotive.

PRELIMINARY TEST PROCEDURE

Whether the compressor is to be mounted on a test stand, Fig. 19, or tested in the locomotive, the following steps should be taken before starting test: Insert a temperature gauge in the pipe plug hole in the crankcase to check temperature rise of lube oil. A 50°-300° F. gauge can be used.


To provide means of relieving air pressure while testing compressor on locomotive, the 170 psi relief valve should be removed and a globe valve installed. Flexible tubing or armored hose can be attached to the valve and placed so that air and vapors will discharge outside the engineroom.

As soon as the compressor is started, either on the test stand or in the locomo-

tive, the lube oil pressure should be approximately 45 psi with cold oil. As the oil temperature increases, the pressure will drop. The oil pressure should be adjusted to 15-20 psi with oil temperature at about 140° F.

COMPRESSOR TEST BREAK-IN RUN

Before the final test runs, the compressor should be given a break-in run for 30 minutes at 425 RPM pumping against a maximum of 10 psi air pressure. On the test stand, a 2" globe valve is used to exhaust the air being pumped and on the locomotive the newly installed globe valve and other air drains can be used. If this does not exhaust sufficient air to keep the pressure at 10 psi, the automatic brake valve can be moved to the full release position.



5720

Fig. 19 — Typical Test Stand Installation

After the half hour run-in, close drain valve or valves and let main reservoir air pressure build up to normal cutout setting of the unloader governor or compressor control switch to cut-in. Repeat several times to make sure suction unloading valve parts and unloader governor or compressor control switch are operating correctly. If any valve or valves fail to unload properly, shut down compressor and repair defect.

FINAL TEST RUNS

Set unloader governor or compressor control switch to cut out at 100 psi and cut in at approximately 90 psi. Open drain sufficiently so that compressor operates at 50% load factor (i.e., unload for the same amount of time that it is loaded), and run for 2 hours at 425 RPM.

Following the first 2 hour final run, reset unloader governor to cut out at normal operating pressure. Operate at 50% load factor under these normal pressures for an additional 2 hours at a compressor speed of 425 RPM.

OPERATING TESTS

Audio inspections of moving parts should be made at regular intervals during the break-in period. If any noise (other than the normal valve click) is apparent, or a regularly occurring thump can be felt by placing hand on compressor, the cause of the noise or vibration should be corrected before attempting any further testing.

The intercooler pressure should be observed during test run, while under load, that it is near 55 psi, as this pressure is an indicator of the valve efficiency. The pressure may vary slightly due to change in air temperature or barometric pressure, but any variation of more than 3 psi above or below normal intercooler

pressure is an indication of a defective valve or valves, the location of which can be found as follows:

1. If intercooler pressure is abnormally high only when pumping, the high pressure suction valve should be inspected.
2. If the intercooler pressure climbs slowly when the compressor is unloaded, the high pressure discharge valve should be inspected.
3. If the intercooler pressure is abnormally low when pumping and drops to zero pressure in less than 3 minutes when unloaded, the low pressure discharge valves should be inspected.
4. If the intercooler pressure is abnormally low when pumping, but drops only a few pounds after being unloaded 3 minutes, the low pressure suction valves should be inspected.

The low pressure discharge valves or low pressure suction valves at fault will usually be indicated by a weak or erratic suction sound, abnormal blowback from air filter, or an excessively hot low pressure discharge valve cover plate.

After the compressor has completed the recommended running time and appears to be working satisfactorily, all valves should be removed and the cylinders inspected for scoring or scratches that might have occurred during assembly or break-in. Brown streaks in the cylinder should not be confused with scratches or scoring, as this is not an abnormal condition and these streaks disappear after the rings and the cylinders have had sufficient running to properly polish themselves together.

The valves may then be replaced and with the compressor running under load, all

gasket joints should be tested for air leaks. This testing may be done with water applied to all gasket joints with an oil can.

After making sure that all valves are again working properly and that all joints are tight and free from leaks, the machine should be given an orifice test. See Fig. 5 for orifice test limits.

COMPRESSOR STORAGE

If the place of storage is near a sea coast or in a damp climate, it is recommended that the compressor be given a 1 hour 50%

load factor test run every 20-90 days during the high humidity season to prevent minute rust areas forming on cylinders and valves. The experience obtained from other similar machinery in the same climate area will assist materially in establishing the optimum interval between storage period retest.

If the tested compressor is to be kept in storage for an indefinite length of time, it should be protected against rust.

If the compressor is to be immediately installed in a locomotive, the slushing with anti-rust oil will not be required.

MAINTENANCE DATA

SPECIFICATIONS

Lube Oil Capacity			
WBO			10-1/2 gal.
WBG			17-1/2 gal.
Valve Rework Limits		<u>Min.</u>	<u>Max.</u>
Valve Seats			
Difference between center boss and valve disc seat010"
Gasket surface flat within005"
Gasket seat width125"	
Valve Bumper			
Distance disc seat surface below center boss surface140"	.156"
Guide finger height must not be greater than center boss height.			
Valve Disc			
Thickness052"	
Lift078"	.102"

Minimum And Maximum Clearances for Rebuild

	MODEL			
	WBO		WBG	
	<u>Min.</u>	<u>Max.</u>	<u>Min.</u>	<u>Max.</u>
Low Pressure Cylinder				
Cylinder - New	7.8750	7.8765	7.0000	7.0015
Piston - New	7.8700	7.8710	6.9955	6.9965
Piston to cylinder				
clearance - New	.0040	.0065	.0035	.0060
Rebuild	.0040	.0085	.0035	.0080
#Piston min. dia.	7.8665		6.992	

	MODEL			
	WBO		WBG	
	<u>Min.</u>	<u>Max.</u>	<u>Min.</u>	<u>Max.</u>
##Cylinder max. dia. Clearance -		7.8795		7.0045
###Side of ring to groove Piston pin	.002 .0013	.004 .004	.002 .0013	.004 .004
####Ring gap	.008		.007	
High Pressure Cylinder				
Cylinder - New	5.7500	5.7515	5.7500	5.7515
Piston - New	5.7460	5.7470	5.7460	5.7470
Piston to cylinder clearance - New	.0030	.0055	.0030	.0055
Rebuild	.0030	.0075	.0030	.0075
#Piston min. dia.	5.7425		5.7425	
##Cylinder max. dia. Clearance -		5.7545		5.7545
###Side of ring to groove Piston pin	.002 .0013	.004 .006	.002 .0013	.004 .006
####Ring gap	.006		.006	
General Clearance Data				
**Main bearing end (cold)	.008	.013	.010	.015
***Connecting rod bearing	.0012	.004	.0012	.004
*Connecting rod side	.013	.065	.013	.065
Oil pump eccentric	.001	.004	.001	.004
Oil pump plunger to body	.001	.003	.001	.003

*Total clearance for all rods on one crankpin.

**If end clearance is more than maximum limit, remove one .005" shim and recheck.

***Do not file cap or rod or use shim stock to tighten. When maximum clearance is reached install new inserts.

#Using a new cylinder at minimum diameter.

##Using a new piston at maximum diameter.

###Side clearance does not apply to spring and ring assemblies.

####Install new rings whenever it is necessary to remove rings from piston or cylinder.

TORQUE VALUES

The following torque values are recommended for fasteners on all air compressors. These torque values are based on threads that are clean and free of burrs and grit. The cleaning solvent (if used) should have a trace of lubricant.

<u>Fastener Size And Thread</u>	<u>Ft-Lbs. Torque</u>	<u>Specific Applications</u>
5/16"-18	8-18	All
3/8"-16	20-30	All
1/2"-13	30-40	All
1/2"-20	40-60	All except piston pin clamp, eccentric, and valve bolts
1/2"-20	80-100	Piston pin clamp screw
1/2"-20	50-60	Valve bolts
1/2"-20	35-45	Oil pump eccentric strap bolt
5/8"-11	50-70	All except cylinder head bolt
5/8"-11	120-130	Cylinder head bolts
5/8"-18	140-160	Connecting rod cap bolts
3/4"-10	130-150	All

EQUIPMENT LIST

	<u>Part No.</u>
Hone Set	8039177
Ring Expanders	
(5-3/4" cylinder)	8205284
(7-7/8" cylinder)	8205286
(7" cylinder)	8205285
Piston Ring Guide	
(5-3/4" cylinder)	8205491
(7-7/8" cylinder)	8205493
(7" cylinder)	8205492
Piston Assembly Fixture	8213878
Connecting Rod Spreader	8214312
Valve Holder	8214755
Oil Seal Guide	8219901
Piston Bushing Anvil	8231756
Piston Bushing Puller	8231757
Piston Bushing Groove Scraper	8231758
Replacer Scraper Blade	8231765
Replacement Blade Guard	8231766