

MAINTENANCE INSTRUCTION



Series Generator Contactor SGC

TABLE OF CONTENTS

DESCRIPTION	2
OPERATION	2
SAFETY PRECAUTIONS	3
MAINTENANCE	4
ARC CHUTE INSPECTION	4
CONTACT INSPECTION AND RENEWAL	4
MAIN AND ARCING CONTACT INSPECTION	4
MAIN AND ARCING CONTACT RENEWAL	5
PILOT CONTACT INSPECTION	6
STATIONARY PILOT CONTACT RENEWAL	6
MOVABLE PILOT CONTACT RENEWAL	8
AUXILIARY INTERLOCK ASSEMBLY	8
DESCRIPTION	8
AUXILIARY INTERLOCK CONTACT INSPECTION	9
AUXILIARY INTERLOCK CONTACT RENEWAL	10
REBUILDING CONTACTOR	11
DISASSEMBLY	16
ASSEMBLY	16
REBUILDING MOVABLE MAIN CONTACT ASSEMBLY	18
ASSEMBLY	20
REBUILDING ARC TIP LATCH ASSEMBLY	22
DISASSEMBLY	22
ASSEMBLY	22
MAIN COIL REPLACEMENT	24
DISASSEMBLY	26
ASSEMBLY	26
PILOT COIL REPLACEMENT	26
CONTACTOR ADJUSTMENT	28
DRIVE PLATE	28
MAIN CONTACT TOUCH POSITION	28
MAIN CONTACT LATCH	29
ARC TIP LATCH	29
MAIN CONTACT OVERTRAVEL CHECK	29
AUXILIARY INTERLOCK TRAVEL	29
PILOT CONTACT GAP	30
ARC TIP RELEASE POINT CHECK	30
ARC CHUTE ELECTRICAL INTERLOCK	30
SERVICE DATA	31

*This bulletin is revised. It supersedes previous issues of this number.

DESCRIPTION

The 5000 ampere series generator contactor SGC, Fig. 1, is a single-pole, normally open device capable of connecting and interrupting D.C. current up to 5000 amperes at 800 volts. It is designed for application in power circuits of diesel-electric equipment.

A four circuit interlock switch with two normally open and two normally closed contacts is enclosed in a dustproof housing. Circuit connections for the interlocks are provided by external faston terminals.

Arc interruption takes place entirely within the arc chute. The magnetic field required to lengthen the arc and speed interruption is provided by permanent magnets on both sides of the arc chute.

The arc chute is designed to operate under normal conditions of rating and environment, with the vent located not closer than 3 inches from an enclosure door or other interfering surface.

OPERATION

The main generator stator in a locomotive has two electrically identical halves. Each half contains three sets of windings, one per AC phase, and a rectifier assembly. Stator design determines that the AC phases from the two stator halves are synchronous. In "non-transition type" main generator locomotives, cabling external to the generator permanently parallels the two generator stator/rectifier halves. In "transition type" main generator locomotives, internal paralleling diode circuits and external series connection switchgear interconnect the two generator stator halves and the load. The two halves supply power to the load either in parallel or in series. In parallel connection, the generator can furnish more current than in series; in series, it can provide higher voltage than in parallel. Changing stator half interconnections from parallel to series, or vice versa is termed generator transition.




Fig 1A — 5000 Ampere
Power Contactor 9330521




Fig. 1B — 5000 Ampere
Power Contactor 9579788

Main generator efficiency, that is, output electrical power produced related to input mechanical power used, varies by a few percent over the locomotive speed range. Efficiency reaches its peak level only at one locomotive speed for "non-transition" type main generators. "Transition" type generators produce an efficiency peak in each operating mode, parallel and series, which occur at two different locomotive speeds. Over the locomotive operating speed range, therefore, generator transition increases average main generator efficiency, which improves fuel economy.

The output from each set of stator windings is applied to a three-phase full wave rectifier bank. At startup, during low speed/high current locomotive operation, the two rectifier banks operate in parallel. At higher locomotive speeds, when current demand begins to decrease and voltage demand begins to increase, contacts of the SGC pilot relay close to energize the SGC main coil which closes the main contacts. The closed main contacts connect the generator rectifier banks in series. A mechanical interlock then opens the SGC pilot coil contacts, dropping the feed to the SGC main coil. The SGC pilot coil holds SGC picked up and the main generator continues to operate in series until the SGC pilot coil feed is interrupted.

SAFETY PRECAUTIONS

WARNING

This power contactor was designed for specific application to circuits of dieselelectric equipment where the circuits and devices are enclosed in suitably protective cabinets. Care has been taken in the design of the equipment to provide for safety of operating and service personnel, provided reasonable care is exercised in the performance of operating and service functions.

The following safety considerations should always be carefully observed in the application, operation, or servicing of the equipment.

1. ELECTRICAL RATINGS of the equipment are values that should be considered to be EXTREMELY DANGEROUS to personnel.
2. EQUIPMENT SHOULD ALWAYS BE COMPLETELY DE-ENERGIZED BEFORE HANDLING OR PERFORMING ANY SERVICE OPERATIONS. De-energizing the operating coil is not sufficient to render the equipment safe; the power lines must also be disconnected or otherwise deenergized. If power lines are not de-energized, all parts of the device should be considered to be at the maximum system voltage.
3. IF INSPECTION OF ENERGIZED EQUIPMENT IS NECESSARY, DO NOT TOUCH OR HANDLE ANY PARTS. DO NOT STAND IN FRONT OF THE EQUIPMENT OR AT CLOSE RANGE TO PERFORM VISUAL INSPECTIONS. The discharge of hot gases and particles is always likely when the contactor is operated in an energized circuit.
4. An electrical interlock is provided in the design to prevent the closing of main contacts until the arc chute is in position. TO AVOID EQUIPMENT DAMAGE OR DANGER TO PERSONNEL, DO NOT APPLY BYPASS DEVICES OR OTHERWISE ATTEMPT TO DEFEAT THE ACTION OF THIS INTERLOCK.
5. NEVER ATTEMPT TO REMOVE THE ARC CHUTE WHILE THE POWER CONTACTOR IS IN AN ENERGIZED OR CLOSED POSITION. Such action is extremely dangerous and would likely result in extensive damage.
6. Operating temperatures for the power contactor are high. Some parts of these devices may normally reach temperatures in excess of 93 C (200 F). SERIOUS BURNS CAN RESULT FROM HANDLING THE EQUIPMENT AFTER IT HAS BEEN IN SERVICE AND BEFORE IT HAS BEEN ALLOWED TO COOL.

MAINTENANCE

Only skilled personnel familiar with electrical equipment and the hazards involved should be permitted to service a power contactor. All safety precautions must be observed.

Minimum maintenance is required to keep the power contactor in serviceable condition. Moving mechanical parts should be free from excess friction. Parts should also be checked for excessive wear. The bearing surfaces of the contactor are designed to operate without lubrication. Do NOT oil or grease at any time.

The contactor must be kept clean, connections must be tight, and should be inspected and serviced at intervals as specified in the applicable Scheduled Maintenance Program.

NOTE
For complete disassembly and assembly procedures, refer to "Rebuilding Contactor."

Torque values for all fasteners unless otherwise noted.

Screw Size	Torque N·m (in-lbs)
10 - 32	2.2 - 3.3 (20-29)
0.250 - 20	5.4 - 8.1 (48-72)
0.312 - 18	9.5 - 13.6 (84-120)
0.375 - 16	16.3 - 23.0 (144-204)

WARNING
High voltage can cause severe injury or death. Remove power supply prior to inspection or servicing.

ARC CHUTE INSPECTION

Remove arc chute (9330521 Contactors) by pulling out with one hand and releasing first the left-hand retaining spring and then the right-hand retaining spring, Fig. 1A.

Remove arc chute (9579788 Contactors) by releasing latch mechanism on right side of the arc chute then rotate the arc chute assembly in the direction shown on the label side of the arc chute. After rotating the arc chute approximately 90 degrees disengage the arc chute from the hinge, Fig. 1B.

Examine the arc chute Figs. 11A- 11B for any signs of: cracks, breaks, holes due to arc erosion, loose parts or foreign material. Blackened ceramic flash plates are still functional provided that none of the ribs are completely eroded away. Damaged arc chute should be repaired or replaced before returning arc chute to service.


NOTE
See "Rebuilding Contactor" for arc chute repair information.

CONTACT INSPECTION AND RENEWAL

NOTE
When arc chute is removed, an electrical interlock prevents the contactor from closing.

MAIN AND ARCING CONTACT INSPECTION

Remove arc chute as described in previous section.



NOTE
This stationary main contact and the stationary arcing contact are secured by the same screws.

28497

Fig. 2 — Main and Arcing Contact Locations

The main and arcing contact inserts, Fig. 2, should be free of foreign matter, but need not be dressed or filed. If foreign material is present, it should be removed by wire brushing. The contacts will operate satisfactorily even though blackened, pitted, or eroded.

1. **Main Contact Inspection:** With arc chute removed, inspect the four movable and four stationary main contacts (8-12 Fig. 3) if any contact insert is eroded or worn to within 0.76mm (.030") of the base material the contact should be replaced with a new contact.
2. **Arcing Contact Inspection:** Place movable arcing contact against the stationary arcing contact (1, 2 Fig. 3) as shown. If the indicated dimension is less than 17.4mm (.685") both stationary and movable arcing contacts should be replaced. Special attention should be given to the stationary contact, as most erosion takes place at this point. Should inspection show that the stationary contact insert has eroded to within 0.76mm (.030") of the base metal or if the gap D_3 Fig. 1 5A- 1 5B between the arc tip lever (8) and the spring support (7) is less than 1.2mm (.050") in the latched position. Both arcing contacts should be replaced with new contacts.

MAIN AND ARCING CONTACT RENEWAL

The stationary and movable main and arcing contacts, Fig. 2, are renewed by removing the screws securing the contacts, applying new contacts, and replacing the screws.

1. **Main Contact Renewal:** Remove screws from main and arcing contacts Fig. 2, as required. Remove failed contacts and replace with new components. Ensure main contacts (8, 12 Fig. 3) are aligned by butting the back of the contact against its support.

Tighten the movable and stationary main contact fastening screws securely. Torque to approximately 6 N·m (50 in/lbs).

2. **Arcing Contact Renewal:** Remove the screws securing arcing contacts (1, 2 Fig. 3).

Apply one or two drops of loctite 222 to each of two #10-32 x.50 screws. Position new movable contact on the end of the arcing contact support arm and tighten securely. Screws should be torqued to 3.3 N·m (20 to 29 in/lb).


Position stationary arcing contact, insert two new # .25-20 x 1.50 screws and lockwashers aligning these contacts with the mounting holes in the positive terminal. Inspect assembly for proper contact tip alignment of both arcing and main contact. Torque screws to 8.1 to 12.2 N·m (72 to 108 in/lb).

NOTE
Whenever replacement of arcing contact is required, a new arcing contact preload spring (10 Fig. 3) should be installed.

PILOT CONTACT INSPECTION

The pilot contacts are a part of the pilot contact-latch assembly, Fig. 4.

Pilot contacts should be replaced with new contacts when contact tips have eroded to within 0.25mm (.010") of base metal.




- | | |
|-------------------------------------|-----------------------------------|
| 1. Movable Arcing Contact | 7. Arcing Contact Support Arm |
| 2. Stationary Arcing Contact | 8. Main Contact |
| 3. #10-32 x .50 Soc. Hd. Cap. Scr. | 9. Positive Terminal |
| 4. #10 Internal Tooth Lk. Washer | 10. Arcing Contact Preload Spring |
| 5. .25-20 x 1.50 Soc. Hd. Cap. Scr. | 11. Negative Terminal |
| 6. .25 I.D. Lockwasher | 12. Main Contact (Movable) |

Fig. 3 — Stationary And Movable Arcing and Main Contacts


STATIONARY PILOT CONTACT RENEWAL

1. Remove nuts, set screw and lockwasher (14) from armature (6) Fig. 4.
2. Remove pivot pins from main armature, release armature from operating lever.
3. Remove screws (13) Fig. 5 securing housing (14) Fig. 5 to pivot block (10) Fig. 5.
4. Remove housing to gain access to stationary contact, remove retaining screw and terminal lead from stationary contact.
5. Remove worn contact and install new contact.
6. Reassemble in reverse order of disassembly.



28499

Fig. 4 — Pilot Contact-Latch Assembly



EE34236

Fig. 5 — Pilot Contact-Latch Assembly, Exploded View

MOVABLE PILOT CONTACT RENEWAL

With pilot contact-latch assembly removed proceed as follows:

1. Proceed as described under "stationary contact removal" until step (3) is completed.
2. Following removal of housing (14 Fig. 5) remove leads from arc chute interlock and free wiring from its cable clamp.
3. Using special tool (Amp. Inc. 458994-1) remove pilot coil leads from metro mate connector (see Fig. 4 insert).

NOTE

Using special extraction tool as follows:

- a. Pull out the plunger of extraction tool all the way out.
 - b. Place outside rim of extraction tool against the socket. This will ensure that the holding ears of the terminals socket are compressed and prevented from damage as the socket is pushed out of the receptacle and will also prevent scoring of the receptacle hole.
 - c. Push in plunger of the extraction tool and the socket should pop out of receptacle.
4. Remove pilot coil leads from cable clamp.
 5. Remove (+) lead connecting main coil to arc chute interlock (see Fig. 21).
 6. Remove the three attaching screws (9 Fig. 5) from the mounting plate.
 7. Remove snap rings and shaft from pivot block armature (9 Fig. 4) along with extension spring (2 Fig. 4) and return spring (16 Fig. 4).
 8. Slide entire pilot contact latch assembly toward the main armature (7 Fig. 4) and remove latch assembly from frame.
 9. With pilot contact latch removed remove pivot block retaining screws (4 Fig. 5) and remove pivot block (10 Fig. 5) and attached armature 17 Fig. 5).
 10. Spread legs of movable contact assembly (1 Fig. 5) one at a time until they are clear of the pivot pins in the pivot block—remove movable contact assembly. Install new movable contacts assembly.

NOTE

Pilot contact coil and related components should be inspected at this time —if inspection shows the need for coil replacement a new coil should be installed at this time.

11. Reassemble pilot contact latch assembly in reverse order of disassembly.
12. Refer to contactor adjustment section of this maintenance instruction for proper adjustment.

AUXILIARY INTERLOCK ASSEMBLY

DESCRIPTION

The auxiliary interlock assembly, Fig. 6, is a four circuit switch with two normally closed and two normally open contacts enclosed in a dustproof housing.

The interlock assembly has three major subassemblies, Fig. 7; two cover assemblies containing the stationary contacts, and a movable contact assembly




Fig. 6 — Auxiliary Interlock Assembly

The nominal travel of the movable contacts is 9.52mm (.375") with over-travel of 2.39mm (.094") beyond nominal in either direction. There is a 2.30mm (.094") travel to contact touch, 2.39mm (.094") additional travel to normal lift position, and 2.39mm (.094") additional travel to internal stop. Movable contact travel is symmetrical each direction from center. The 2.39mm (.094") normal life permits an adjustment tolerance of 0.81mm (.032").

The nominal position in one direction occurs when the short end of the movable contact assembly is flush with the end of the auxiliary interlock housing. The nominal position in the other direction occurs when the 0.41 mm (.016") step on the longer end (threaded end) of the movable contact assembly is flush with the end of the auxiliary interlock housing.

AUXILIARY INTERLOCK CONTACT INSPECTION

1. Remove auxiliary interlock support bracket (7, Fig. 7) from frame.
2. Remove auxiliary interlock (1, Fig. 7) from interlock support bracket (7).




Fig. 7 — Auxiliary Interlock Assembly, Partial Exploded View


3. Remove two parting screws (3, Fig. 7) and carefully separate covers.
4. Carefully remove movable contact assembly, Fig. 8. The movable contact assembly can be removed from the cover-half without danger of losing small parts.
5. Inspect the movable contacts in the movable contact assembly and inspect the stationary contacts in each cover-half. The contact maximum wear allowance is 0.25mm (.010") of each contact. New contact tips are 0.38mm (.015") thick. If the movable contacts are worn beyond specified limits, the movable contacts should be replaced with new contacts. If the stationary contacts in the interlock cover halves are worn or loose, the interlock assembly should be replaced with a new interlock assembly.

AUXILIARY INTERLOCK CONTACT RENEWAL


If determined after inspection that interlock movable contacts should be renewed, proceed as follows:

CAUTION

Each movable contact must be positioned properly and not inverted because this could cause malfunction of the contactor. Carefully note the position of each contact before removal. The location and attitude of all parts with respect to the molded key on the contact carrier must be correct. Refer to Fig. 9.



28503



28504

Fig. 8 — Movable Contact Assembly in Interlock

Fig. 9 — Interlock Movable Contact Assembly

The movable contact should be disassembled ONLY in an area where the small parts will not be lost if accidentally dropped.

1. Hold contact carrier, Fig. 9, in one hand and tilt forward the movable contact to be removed.
2. Using a screwdriver or similar tool, push down on end of contact spring. Pull out spring while pushing down to free contact spring from its retainer. Remove contact spring.
3. Turn movable contact sideways (rotate 90 degrees) and remove movable contact.
4. To install new movable contact, reverse Steps 1, 2, and 3. Ensure each movable contact is positioned correctly.

CAUTION

When placing movable contact assembly into interlock cover, ensure that each movable contact tip is mated to each stationary contact. It is possible to place the contact carrier into the interlock cover half so that the movable contact tips will not engage the stationary contacts.

5. When all movable contacts have been replaced with new contacts, very carefully place contact carrier into interlock cover-half, Fig.8. Ensure each movable contact tip is mated to each stationary contact. Position contact carrier key so that the key is inside the C-D, G-H cover. A molded projection inside the A-B, E-F cover further assures a correct assembly.
6. Gently slide insulator up until the insulator fits into notches in the interlock cover half as shown in Fig.8.
7. Hold the insulator in place and move contact carrier from end to end to ensure movable contacts are positioned correctly.
8. Apply other cover half in interlock assembly. Ensure the movable contact tips are mated to the stationary contacts. Fasten securely. Move contact carrier from end to end to ensure the movable contacts are positioned correctly.
9. Mount interlock assembly, (Fig.6), to the interlock support bracket and attach interlock support bracket to frame using lockwashers and screws. Ensure the steel interlock operating lever is aligned inside slot in interlock operator, as shown in Fig. 6, then fasten securely.
10. With the contactor in de-energized position, ensure that 0.41 mm (.016") step, Fig.9, on movable contact carrier molding is flush with the end of the housing within 0.81mm (.032"). If adjustment is required, adjust by bending the steel interlock operating lever.

REBUILDING CONTACTOR


Under ordinary circumstances, replacement of the contactor contacts and interlock contacts is the extent of the periodic maintenance required to assure reliable operation. However, if the contactor is to be serviced or rebuilt for other reasons, use the following procedure. Refer to Fig. 10A (9330521) or 10B (9579788) Contactors, Exploded Views as required during rebuilding.

WARNING

Do not disassemble contactor in the cabinet. Disconnect the contactor power cables and leads to the interlock assembly and then remove the contactor from the cabinet.

Torque values for all fasteners unless otherwise noted.

Screw Size	Torque N·m (in-lbs)
10-32	2.3 - 3.3 (20-29)
0.250-20	5.4 - 8.1 (48-72)
0.312-18	9.5 - 13.6 (84-120)
0.375-16	16.3 - 23.0 (144-204)



34456

Fig. 10A — Contactor, Exploded View 9330521 (Sheet 1 of 2)

- | | | |
|--|--|---|
| 1. Frame | 36. Interlock | 69. Screw, 0.250—20 x 1.25" Socket Head Cap |
| 2. Screw, 0.318—18 x 0.75" Hex Head Cap | 37. Interlock Operator | 70. Movable Arc Tip |
| 3. Lockwasher, 0.312" Spring | 38. Washer, 0.250" Belleville | 71. Arc Tip Lever |
| 4. Screw, 0.250—20 x 0.50" Socket Head Cap | 39. Screw, 0.250—20 x 1.25" Hex Head Cap | 72. Arc Tip Preload Spring |
| 5. Lockwasher, 0.250" Spring | 40. Flat Washer, 0.250" | 73. Flat Washer, 0.375" |
| 6. Screw, #8-32 x 1.50" x Slotted Round Head | 41. Pilot Contact- Latch Assembly | 74. Hex Socket Hex Shoulder Screw |
| 7. Lockwasher, #8 Internal Tooth | 42. Retaining Ring | 75. Flexible Lead |
| 8. Latch Spring | 43. Bearing Pin | 76. Screw, 0.250—20 x 1.00" Hex Head Cap |
| 9. Screw, 0.250—20 x 0.50" Hex Head Cap | 44. Screw, 0.312—18 1.00" Socket Head Cap | 77. Support |
| 10. Flat Washer, 0.375" | 45. Operator Lever | 78. Spring |
| 13. Terminal Socket | 46. Link | 81. Flexible Lead |
| 14. Screw, 0.312—18 x 0.62" Cup P. Socket Head | 47. Insulating Strip | 82. Nut, #8-32 Hex |
| 15. Stop Block | 48. Locknut, 0.312—18 Hex | 83. Flat Washer, #8 Brass |
| 16. Screw, 0.250—20 x 0.62" Socket Head Cap | 49. Flat Washer 0.312" | 84. Insulator |
| 17. Screw, 0.375" x 1.00" Hex Socket Flat Head | 50. Spring Mounting Molding | 85. Connector Tab |
| 18. Lockwasher, 0.375" CTSK | 51. Trip Retainer | 86. Contact Blade |
| 19. Yoke | 52. Drive Plate | 87. Contact Blade |
| 20. Screw, #10-32 x 0.50" Socket Head Cap | 53. Flat Washer, 0.197" | 88. Insulator |
| 21. Washer, #10 Internal Tooth | 54. Screw, #10-32 x 0.75" Socket Head Cap | 89. Insulator Tube |
| 22. Magnet Core | 55. Stand Off Insulator | 90. Insulator |
| 23. Main Coil | 56. Negative Terminal | 91. Bearing Pin |
| 24. Pole Plate | 57. Screw, 0.312—18 x 0.75" Socket Head Cap | 92. Extension Spring |
| 25. Lockwasher, 0.250" CTSK | 58. Movable Contact Support Assembly | 93. Movable Contact Assembly (NEG) |
| 26. Screw, 0.250" x 0.50" Hex Socket Flat Head | 59. Main Contact Spring | 94. Bushing |
| 27. Armature Spring | 60. Main Contact | 105. Screw |
| 28. Main Armature | 61. Screw, 0.250—20 x 1.00" Socket Head Cap | 106. Housing Assembly Auxiliary Contact |
| 29. Pin | 62. Clamping Plate** | 107. Opening Spring |
| 30. Lockwasher, 0.250" Internal Tooth | 63. Screw, 0.250—20 x 1.00" Hex Socket Flat Head | **Prior to Serial #84E03M32135-032 should be used |
| 31. Screw, 0.250—20 x 0.62" Hex Socket Set | 64. Arc Tip | |
| 32. Nut, 0.250—20 Hex | 65. Screw, 0.250—20 x 1.50" Socket Head Cap | |
| 33. Arc Chute | 66. Positive Main Terminal | |
| 34. Interlock Support Bracket | 67. Arc Chute Support Bracket | |
| 35. Screw, #10-32 x 0.38" Fillister Head | 68. Arc Tip Latch Assembly | |

Fig. 10A — Contactor 9330521 (Sheet 2 of 2)




Fig. 10B — Contactor, Exploded View 9579788 (Sheet 1 of 2)

- | | | |
|--|--|--|
| 1. Frame | 37. Interlock Operator | 71. Arc Tip Lever |
| 2. Screw, 0.318—18 x 0.75" Hex Head Cap | 38. Washer, 0.250" Belleville | 72. Arc Tip Preload Spring |
| 3. Lockwasher, 0.312" Spring | 39. Screw, 0.250—20 x 1.25" Hex Head Cap | 73. Flat Washer, 0.375" |
| 4. Screw, 0.250—20 x 0.50" Socket Head Cap | 40. Flat Washer, 0.250" | 74. Hex Socket Hex Shoulder Screw |
| 5. Lockwasher, 0.250" Spring | 41. Pilot Contact - Latch Assembly | 75. Flexible Lead |
| 6. Screw, #8-32 x 1.50" x Slotted Round Head | 42. Retaining Ring | 76. Screw, 0.250—20 x 1.00" Hex Head Cap |
| 7. Lockwasher, #8 Internal Tooth | 43. Bearing Pin | 77. Support |
| 9. Screw, 0.250—20 x 0.50" Hex Head Cap | 44. Screw, 0.312—18 x 1.00" Socket Head Cap | 78. Spring |
| 10. Flat Washer, 0.375" | 45. Operator Lever | 81. Flexible Lead |
| 13. Terminal Socket | 46. Link | 82. Nut, #8-32 Hex |
| 14. Screw, 0.312—18 x 0.62" Cup Socket Set | 47. Insulating Strip | 83. Flat Washer, #8 Brass |
| 15. Stop Block | 48. Locknut, 0.312—18 Hex | 84. Insulator |
| 16. Screw, 0.250—20 x 0.62" Socket Head Cap | 49. Flat Washer 0.312" | 85. Connector Tab |
| 17. Screw, 0.375" x 1.00" Hex Socket Flat Head | 50. Spring Mounting Molding | 86. Contact Blade |
| 18. Lockwasher, 0.375" CTSK | 51. Trip Retainer | 87. Contact Blade |
| 19. Yoke | 52. Drive Plate | 89. Insulator Tube |
| 20. Screw, #10-32 x 0.50" Socket Head Cap | 53. Flat Washer, 0.197" | 90. Insulator |
| 21. Washer, #10 Internal Tooth | 54. Screw, #10-32 x 0.75" Socket Head Cap | 91. Bearing Pin |
| 22. Magnet Core | 55. Stand Off Insulator | 92. Extension Spring |
| 23. Main Coil | 56. Negative Terminal | 93. Movable Contact Assembly (NEG) |
| 24. Pole Plate | 57. Screw, 0.312—18 x 0.75" Socket Head Cap | 94. Bushing |
| 25. Lockwasher, 0.250" CTSK | 58. Movable Contact Support Assembly | 95. Socket HD Screw #10-32 x 1.500" |
| 26. Screw, 0.250" x 0.50" Hex Socket Flat Head | 59. Main Contact Spring | 96. Socket HD Screw #10-32 x 0.375" |
| 27. Armature Spring | 60. Main Contact | 97. Block, Arc Chute Base |
| 28. Main Armature | 61: Screw, 0.250—20 x 1.00" Socket Head Cap | 98. Block, Arc Chute Support |
| 29. Pin | 62. Clamping Plate | 99. Block, Arc Chute Guide |
| 30. Lockwasher, 0.250" Internal Tooth | 63. Screw, 0.250-20 x 1.00" Hex Socket Flat Head | 100. Spring, Stop |
| 31. Screw, 0.250—20 x 0.62" Hex Socket Set | 64. Arc Tip | 102. Arc Chute Retaining Spring |
| 32. Nut, 0.250—20 Hex | 65. Screw, 0.250—20 1.50" Socket Head Cap | 103. Insulation Sheet |
| 33. Arc Chute | 66. Positive Main Terminal | 104. Arc Chute Support Assembly |
| 34. Interlock Support Bracket | 68. Arc Tip Latch Assembly | 105. Screw |
| 35. Screw, #10-32 x 0.38" Filister Head | 69. Screw, 0.250—20 x 1.25" Socket Head Cap | 106. Housing Assembly Auxiliary Contact |
| 36. Interlock | 70. Movable Arc Tip | 107. Opening Spring |

Fig. 10B — Contactor, Exploded View 9579788 (Sheet 2 of 2)

ARC CHUTE ASSEMBLY MAINTENANCE**NOTE**

It is not advisable to completely disassemble arc chute in the field. However, the following components may be replaced if inspection shows them to be damaged. See Fig. 11A (9330521 contactor) or Fig. 11 B (9579788 contactor).

- | | |
|-----------------------------|----------------|
| 1. Arc chute latch assembly | 2. Arc runners |
| 3. Latch pin | 4. Stop |

WARNING

Arc chute halves contain very strong magnets which pull the two halves toward each other with a strong force. Do not place fingers between separated arc chute halves. The magnetic force can cause the arc chute halves to snap together suddenly, with sufficient force to badly pinch a finger or fingers.

DISASSEMBLY

1. Remove retaining hardware (2 & 7, Fig. 11A and 11B), screws, lockwashers, washers, and nuts.
2. Place arc chute on a table with the label side down and the white arrows on the magnets of pole plate magnet assembly (9, Fig. 11A and 11B) pointing down.
3. With a pair of screw drivers or similar tools, separate the arc chute halves by prying them apart. Be careful not to pinch fingers as cautioned above. Remove upper arc chute half.
4. With arc chute halves separated the following components may be removed by lifting them out of their molding half retaining holes or slots.

For 9330521 contactors, refer to Fig. 12:

1. Latch Pin (2)
2. Core (3)
3. Arc Runner (4)
4. Stop (5)

For 9579788 contactors, refer to Fig. 13:

1. Latch Pin (2)
2. Core (3)
3. Arc Runner (4)
4. Latch & Pin Assembly (5)


5. Replace damaged components with new components.

NOTE

If at any time during disassembly of the arc chute, the magnets (or magnet pole plate) should become dislodged from the arc chute molding halves, further repairs should be discontinued and the arc chute assembly should be replaced with a new arc chute.

ASSEMBLY**WARNING**


It is extremely important that the components of the arc chute assembly be placed in proper orientation to the magnetic field established by the arc chute magnets. Failure to install the latch mechanism (5, Fig. 11B 9579788), or for contactors (9330521) the stop (6, Fig.11A) in their proper locations will result in the arc chute failing to interrupt the arc, and the contactor will be destroyed.



28506

- | | |
|---------------------------|---|
| 1. Arc Chute Molding | 6. Stop |
| 2. Retaining Hardware | 7. Screw 10-32 x 12.70 mm (.050") - Two |
| 3. Latch Pin | 8. Screw 10-32 x 12.70 mm (.050") - One |
| 4. Arc Runner | 9. Pole Plate Magnet Assembly |
| 5. One-inch Square Magnet | |

Fig. 11A — Arc Chute 9330521 Contactor



- | | |
|-----------------------|---|
| 1. Arc Chute Molding | 6. Ceramic Flash Plate |
| 2. Retaining Hardware | 7. Screw 10-32 x 12.70 mm (.050") - Two |
| 3. Latch Pin | 8. Screw 10-32 x 12.70 mm (.050") - One |
| 4. Arc Runner | 9. Pole Plate Magnet Assembly |
| 5. Arc Chute Latch | |

Fig. 11B — Arc Chute 9579788 Contactor

1. Place the labled half of the arc chute on the work surface (A) label side down, and (B) with flat side of arc chute facing the person repairing the arc chute.
2. Install the two arc runners in their appropriate slots in the arc chute half.
3. Install the arc chute latch assembly and pin (5, Fig. 11 B - 9579788 contactors) in its mounting hole on the RIGHT SIDE of the arc chute half.

NOTE

For 9330521 contactors, install stop (6, Fig. 11A) in the slot provided on the LEFT SIDE of the arc chute half.

4. Install hinge pin (3, Fig. 11A) in locating hole on the left side of arc chute half.

NOTE

9330521 contactors have two latch pins (3, Fig. 11A) installed, one on either side of the arc chute (see Fig. 11A).

5. Being careful to keep fingers from between arc chute halves, install remaining half of arc chute and secure with attaching hardware.

NOTE


Should arc chute magnets or pole plates become dislodged during assembly, discontinue repairs and replace arc chute with a new arc chute assembly.

REBUILDING MOVABLE MAIN CONTACT ASSEMBLY

DISASSEMBLY

If movable contact support (2, Fig. 14), main contact springs (7), or spring mounting molding (8) require replacement, proceed as follows:

1. Remove the end of the flexible lead (4, Fig. 14) that attach to negative terminal (5). Remove support screws and remove support (15) along with flexible lead.
2. Remove screws that secure the spring mounting (8, Fig. 14) and insulating strip (9) to the operator lever (10).
3. Loosen two screws that secure drive plate (13, Fig.14 View A) to the spring mounting molding (8). Push drive plate (13) as far away from arc tip latch assembly (11) as possible and, then lightly retighten screws.
4. Push trip operator (1, Fig. 15) as far to the right as possible and release trip operator (5).
5. Remove three screws that attach standoff insulators (6, Fig. 14) to frame (14).
6. Remove movable main contacts (1, Fig. 14), movable contact supports (2), clamping plates (3), negative terminal (5), and standoff insulators (6) as an assembly. Refer to Figs. 10A and 10B, Item 93.
7. Remove screws (63, Fig. 10A & 10B), lockwashers (25), and clamping plates (62) securing movable contact supports (58) to negative terminal (56).
8. Remove locknuts (48, Fig.10A &10B) and flat washers (49) securing each movable contact to the spring mounting molding (50). Remove main contact spring (59) and spring mounting molding (50).




- 1. Arc Chute
- 2. Latch Pin
- 3. Core
- 4. Arc Runner
- 5. Stop

NOTE

With the arc chute label side down, the notch for the stop (5) is located on the left side as shown


Fig. 12 — Arc Chute Molding Assembly (9330521 Contactor)



- 1. Arc Chute
- 2. Hinge Pin
- 3. Core
- 4. Arc Runner
- 5. Latch and Pin Assembly

Fig. 13 — Arc Chute Molding Assembly (9579788 Contactor)

- 1- MOVABLE MAIN CONTACT
- 2- MOVABLE CONTACT SUPPORT
- 3- CLAMPING PLATE
- 4- FLEXIBLE LEAD
- 5- NEGATIVE TERMINAL
- 6- STANDOFF INSULATOR
- 7- MAIN CONTACT SPRING
- 8- SPRING MOUNTING MOLDING
- 9- INSULATING STRIP
- 10- OPERATOR LEVER
- 11- ARC TIP LATCH ASSEMBLY
- 12- TRIP RETAINER
- 13- DRIVE PLATE
- 14- FRAME
- 15- SUPPORT



VIEW A. EXPLODED

EE34238

- 1. Movable Main Contact
- 2. Movable Contact Support
- 3. Clamping Plate
- 4. Flexible Lead
- 5. Negative Terminal
- 6. Standoff Insulator
- 7. Main Contact Spring
- 8. Spring Mounting Molding
- 9. Insulating Strip
- 10. Operator Lever
- 11. Arc tip Latch Assembly
- 12. Trip Retainer
- 13. Drive Plate

28510

Fig. 14 — Movable Main Contact Assembly

ASSEMBLY

Replace movable contact support (2, Fig. 14), main contact spring (7), or spring mounting molding (8) with new parts as required. Reassemble movable main contact assembly as follows:

NOTE

Prior to applying Loctite retaining compound in Step 1, Loctite cleaner-activator can be used to ensure good bond.

1. Place movable contact support stud (4, Fig. 16) through main contact spring (5). Seat main contact spring (5) in spring pocket of spring mounting molding (3) and place stud (4) through hole in spring mounting molding (3). Apply Loctite Grade A-A retaining compound to locknut threads and apply locknut (2) and washer (1) to movable contact support stud (4).


Engage locknut (2) with one or two turns. Repeat this procedure for all movable contact supports which were removed.

2. Tighten locknut (2, Fig. 16) until $60.02\text{mm} \pm 0.02$ (2.363" \pm .001) is obtained between the end of the spring mounting molding (3) and the support (6). Adjustment torque of locknut (2) should be a minimum of 2.8 N m (25 in/ lbs). If not, replace locknut with a new one.
3. Loosely attach all movable contact supports and clamping plates (3, 2, Fig. 14), which were removed to negative terminal (5). Do not tighten at this time.
4. Replace (any) movable main contacts (8, 12, Fig. 3) that have been removed, taking care to position contact against contact locating surface.
5. Place movable contact assembly (1, 2, 3, 5 and 6, Fig. 14) in proper position and attach standoff insulators (6) to frame (14) with three screws and lockwashers. Tighten securely.
6. Position trip retainers (5, Fig. 15) inside of window of trip operator (1). Ensure drive plate (4) is positioned with adjustment screws (3) against the ends of adjustment slots in drive plate (4).

NOTE


Refer to contactor adjustment section for proper drive plate adjustment procedure.

7. Place insulating strip (9, Fig. 14) between spring mounting molding (8) and operator lever (10). Attach spring mounting molding (8) and operator lever (10) with two screws and lockwashers. Tighten securely.
8. Install support (15, Fig. 14) to frame assembly. Attach ends of flexible lead (4) to negative terminal (5) and support (15) with screws and lockwashers.
9. Tighten screws that fasten movable contact supports (2, Fig. 14) to negative terminal (5) securely. Check for freedom of movement of movable contact support stud in spring mounting molding (8). If rubbing exists, loosen screws securing movable contact supports (2) to negative terminal (5) and move movable contact support (2) to relieve friction. Retighten screws and recheck for freedom of movement.
10. Refer to Contactor Adjustment section of this Maintenance Instruction to adjust contactor.



EE34239

Fig. 15A — Drive Plate Adjustment 9330521 Contactor



EE34240

Fig. 15B — Drive Plate Adjustment 9579788 Contactor

REBUILDING ARC TIP LATCH ASSEMBLY**NOTE**

Depending on type of contactor being rebuilt, some steps described in this section may be deleted. For 9330521 contactors follow steps I through 11. For 9579788 contactors steps I and 3 may be omitted.

DISASSEMBLY

If any parts of the arc tip latching assembly are worn or damaged, proceed as follows:

1. Remove movable arc tip (3, Fig. 17).
2. Remove arc tip preload spring (5, Fig. 17).
3. Remove hex socket shoulder screw (8, Fig. 17). Note the location of the flat washers.
4. Loosen two screws that secure drive plate (4, Fig. 15) to the spring mounting molding (6). Push drive plate (4) as far away from arc tip latch assembly (11, Fig. 14) as possible and then lightly retighten screws.
5. Push trip operator (1, Fig. 15) as far to the left as possible and release trip operator (1) from trip retainer (5) (as shown in illustration).

CAUTION

In Step 6, never trip the arc tip latch assembly (2, Fig. 17) without restraining the spring support (4) because the resultant impact forces can permanently damage spring mounting molding and other parts.

6. Remove two screws securing the arc tip latch assembly (2, Fig. 17) to the positive main terminal (1) and slide arc tip latch assembly (2) from the end of arc tip lever (6) (type 9330521). For 9579788, latch assembly may be lifted off of arc tip lever at this time). Remove latch assembly from contactor.
7. Remove two extension springs (18, Fig. 18).
8. Remove the RTV compound surrounding retaining ring (17, Fig. 18) and remove retaining ring (17).
9. Push on free end of spring support (13, Fig. 18) with enough force to compress compression spring (5) slightly and remove pin (4). Be careful not to lose spacers (10 and 12).

NOTE


On current contactor (9579788) spacers (10-12, Fig. 18) have been replaced by a single bearing/washer assembly.

10. Remove spring support (13, Fig. 18).
11. Replace all worn or damaged parts with new parts.

ASSEMBLY**NOTE**


For 9330521 contactor, follow steps I through 11. For 9579788 contactors, steps 8 and 9 may be omitted.

1. Lay spring support (13, Fig. 18) in slot in trip operator (11), holding trip operator (11) in place against the spring support (13). Insert flat end of spring support (13) through spring cup washer (6) and compression spring (5). Align flat end of spring support (13) with slot in housing (1). Push spring support into place.



EE34241.

Fig. 16 — Movable Contact Support Adjustment



- | | |
|--|------------------------------|
| 1. Positive Main Terminal | 5. Arc Tip Preload Spring |
| 2. Arc Tip Latch Assembly | 6. Arc Tip Lever |
| 3. Movable Arc Tip | 7. Spring Mounting Screw |
| 4. Spring Support (Arc Tip Latch Assembly) | 8. Hex Socket Shoulder Screw |

Fig. 17 — Arc Tip Latch Assembly

2. Hold spring support (13, Fig. 18) in position by placing the assembly between the jaws of a large vise, blocks of wood nailed to a board, or similar means of retention.
3. Refer to Fig. 18 and assemble the following: bearing pin (15), bearing (16), both retaining rings (8), both rollers (9), and bearing pin (14) to both trip links (7). Place this assembly inside of housing (1) with one trip link (7) on each side of spring support (13). Align the holes in both trip links (7) with the hole that pin (4) goes through and the slot in the spring support (13).
4. Place spacers (10 and 12) in proper positions and secure with pin (4) and retaining ring (17).
5. Replace extension springs (18) and remove assembly from vise or holding fixture. Cover both ends of pin (4) and retaining ring (17) with RTV compound for electrical insulation.
6. Place arc tip lever (6, Fig. 17) through window in spring support (4) and secure arc tip latch assembly (2) loosely to positive main terminal (1) with screws, lockwashers, and flat washers. (Type 703 - For type 703A arc tip latch assembly may be positioned over movable arc tip lever and attached loosely to positive terminal at this time.)

WARNING

In step 7, failure to key trip retainer (5, Fig. 15) with drive plate (4) will result in failure to interrupt the arc. The contactor will be destroyed.

7. Position trip retainer (5, Fig. 15) inside of window of trip operator (1). Drive plate (4) must be positioned with adjustment screws (3) against ends of adjustment slots in drive plate (4) while engaging trip retainer (5). Key trip retainer (5) with drive plate (4). See warning above.

NOTE

Prior to applying Loctite retaining compound in steps 8 and 9, Loctite cleaner-activator can be used to ensure a good bond.

8. Place hex socket shoulder screw (8, Fig. 17) through washers and arc tip lever (6). If initial positions of washers was not noted, locate the washers so that the arc tip lever (6) passes approximately through the center of the window in the spring support (4). Apply Loctite Grade 271 retaining compound to threads of hex socket shoulder screw (8) and fasten securely.
9. Fasten movable arc tip (3) to arc tip lever (6) with lockwasher and screw. Apply Loctite Grade 222 to screw threads and fasten securely.
10. Replace arc tip preload spring (5) with new preload spring.
11. Refer to Contactor Adjustment section of this Maintenance Instruction to adjust contactor.

MAIN COIL REPLACEMENT

If main coil, Fig. 19, requires replacement, proceed as follows:

NOTE

Unless it is absolutely necessary, at no time should the magnet yoke (1, Fig. 20) be removed from the frame of the contactor. Removal of this component will make adjustment of the contactor more difficult




Fig. 18 — Arc Tip Latch Assembly, Exploded View
 9330521 Contactor




Fig. 19 — Main Coil Assembly

DISASSEMBLY

1. Loosen hex nuts (16, Fig. 20) and back out two set screws (15) and remove pins (13).
2. Remove two screws (5) securing main armature (12) to yoke (1). Remove armature (12).
3. Remove armature spring (11).
4. Remove screw (10) and pole plate (8).
5. Note the positions of the electrical leads attached to the main coil and remove leads. Slide coil (7) from magnet core (6) and replace coil.

NOTE

If difficulty in removing the magnet coil (7) from the magnet core (6) is encountered, the coil and core may be removed as an assembly by removing core mounting bolt (2, Fig. 20). The magnet core may then be removed from the core by suitable means, or the entire assembly may be replaced.

ASSEMBLY

1. Insert new main coil (7, Fig. 20) and replace electrical leads. Polarity MUST be as shown in Fig. 21.
2. Reposition pole plate (8, Fig. 20) and secure using lockwasher (9) and screw (10).
3. Engage armature spring (11) between frame and main armature (12).
4. Reposition main armature (12) and secure to yoke (1) with lockwashers (4) and screws (5).
5. Align holes in main armature (12) with holes in ends of operator lever (17) legs and insert pins (13). Secure pins (13) with setscrews (15) and secure setscrews (15) with lockwashers (14) and hex nuts (16).
6. Refer to Contactor Adjustment section of this Maintenance Instruction to adjust contactor.


PILOT COIL REPLACEMENT

The pilot coil is part of the pilot contact latch assembly (7, Fig. 4) to replace pilot coil it is necessary to remove the pilot contact latch assembly from the contactor.

NOTE


The procedure for removing the pilot contact latch assembly is outlined in the section of this instruction manual entitled "STATIONARY PILOT CONTACT RENEWAL".

1. With pilot contact latch removed. Remove flat head screws (4, Fig. 5) that secure pivot block (10, Fig. 5) to mounting plate (6, Fig. 5) remove pivot block along with attached components.
2. Remove screw (23, Fig. 5).
3. Remove pole plate (21, Fig. 5) core (20, Fig. 5) and spacer (19, Fig. 5).
4. Remove old coil (18, Fig. 5) and replace it with a new coil.
5. Reassemble in reverse order of disassembly.



EE34242

Fig. 20 — Main Coil Assembly, Exploded View



28517

Fig. 21 — Wiring Pictorial Diagram

CONTACTOR ADJUSTMENT

After rebuilding the contactor or any of its major subassemblies, the following conditions should be checked and adjustments made if required.

DRIVE PLATE

- la. Drive plate adjustment 9330521 contactor.

Loosen adjustment screws (3, Fig. 15 A). Position drive plate (4) so that the drive plate (4) extends through the trip operator (1) a minimum of 0.76mm (.030"), with minimum clearance (free play removed) between trip operator (1) and the spring support (7). The drive plate (4) protrusion through the trip operator dimensions is shown as D2 on Fig. 15A.

The clearance between the spring support (7, Fig. 15A) and the drive plate (4) must also be a minimum of 0.76mm (.030"). This clearance is shown as D1 on Fig. 15A.

Drive plate (4, Fig. 15A) should be centered with respect to the spring support (7) within 0.76mm (.030").

When these conditions are met, tighten adjustment screws (3, Fig. 15A) securely.

- lb. Drive plate adjustment 9579788 contactors. Loosen adjustment screws (3, Fig. 15B) and position drive plate (4, Fig. 15B) and trip retainer assembly in the center of the window in the trip operator (1, Fig. 15B). Set the shoulder of the drive plate (4, Fig. 15B) such that it is flush within .010" with the surface of the spring mounting molding (6, Fig. 15B).

With drive plate properly positioned on spring mounting molding, there should be a minimum contact between the drive plate and the spring carrier (8, Fig. 15B) of .125" (shown as dimension D1).

When these conditions are met, tighten adjusting screws (3, Fig. 15B) securely.

MAIN CONTACT TOUCH POSITION

1. Note position of electric leads attached to main coil (5, Fig. 19) and remove leads.

NOTE

To check out the contactor, a power supply capable of producing 50 volts DC, 26 amperes should be used. If a power supply capable of producing 26 amperes at 50 volts DC is not available, a smaller power supply can be used, but the main armature closing must be manually assisted.

2. Attach power supply to main coil positive and negative terminals. Refer to Fig. 19.
3. Place a 1.778mm (.070") shim of magnetic steel in the gap between the main armature (2, Fig. 19) and yoke leg (4) at a point farthest from the main armature pivot point. Apply 26 amperes at 50 volts DC to main coil (5) which will cause the main armature (2) to close, clamping the shim in place. If a smaller power supply is being used, manually assist the armature closing..

NOTE

After clamping has occurred, reduce coil voltage to 9 volts DC, or damage to the coil will result

NOTE

Check contact touch at this time, if contacts are out of adjustment proceed with step (4).

4. Loosen two screws (18, Fig. 20) securing the yoke (1) to the frame. Position yoke (1) and main armature assembly (12) so that the main contacts, just touch or have a maximum gap of 0.13mm (.005"). Secure yoke (1) to frame tightly with the two screws (18).
5. De-energize the power supply. Remove 1.778mm (.070") shim.

MAIN CONTACT LATCH

1. Repeat Step 3 of Main Contact Touch Position procedure except close the main armature (2, Fig. 19) onto a 0.28mm (.011") magnetic steel shim in the main armature gap.
2. Loosen three screws (9, Fig.5) securing pilot contact-latch assembly (7, Fig. 4) to frame. Manually close pilot contact-latch assembly armature (17, Fig. 5). Position pilot contactlatch assembly so that the armature (17) just closes without free-play. Secure with three screws (9). Torque to 14-19 N m (120-168 in-lbs).

ARC TIP LATCH

1. Repeat Step 3 of Main Contact Touch Position procedure except close the main armature (2, Fig. 19) onto a 0.38mm (.015") magnetic steel shim in the main armature (2) gap.
2. Loosen screws (21, Fig. 18) securing arc tip latch assembly (2, Fig. 17) to positive main terminal (1). Screws must be tight enough to prevent free movement of arc tip latch assembly, but loose enough for arc tip latch assembly to be moved when tapped with a rubber hammer.
3. Position arc tip latch assembly(Fig.17) by tapping with a rubber hammer so that the bearing (16, Fig.18) has just enough clearance to allow the mechanism to latch. Secure with the two screws. Torque to 8-12 N m (60-89 in-lbs).
4. De-energize the main coil and disconnect the power supply leads. Replace the contactor leads that were removed from main coil. Ensure polarity is as shown in Fig. 21.

MAIN CONTACT OVERTRAVEL CHECK

Main contact (Fig. 2) should have an overtravel of 1.37-2.03mm (.054"-.080") when the contactor is in the latched closed position. If this condition is not met, repeat the three adjusting procedures just completed until correct overtravel is obtained.

NOTE

With the main armature in the sealed position (zero gap) the main contacts must be free to deflect without jamming.

AUXILIARY INTERLOCK TRAVEL

With coil de-energized, step at operator end of interlock carrier shall be within .030 in. of interlock housing. With main contact latch sealed, free end of interlock carrier shall be within .030 of interlock housing. To make adjustments, bend interlock operator which is welded to operator lever assembly (see Fig. 6).

PILOT CONTACT GAP

There shall be a .086" minimum contact gap with main device both open and closed. There shall be 0.060" minimum contact travel after touch, at maximum movable contact travel. Bend movable contact support for adjustment if required. Refer to Fig. 5.

Energize the contactor several times at 74 volts DC while inspecting for proper operation.


ARC TIP RELEASE POINT CHECK

After all adjustments are complete, close the main armature. Allow main armature to open slowly. Arc tip latch (2, Fig. 17) must trip by the pull of main armature spring when the main contact gap is .150 inch minimum and not less than .050" from the full open position.

ARC CHUTE ELECTRICAL INTERLOCK

Contactor will not operate without arc chute in place because of this interlock.

The position of the blades of the electrical interlock should be as shown in Fig. 22. If they are not, bend the blades to the dimensions specified.



28518

Fig. 22 — Arc Chute Electrical Interlock

SERVICE DATA

SPECIFICATIONS

MAIN CONTACTS

Contact Rating, Continuous	5000 Amperes
Contact Wear Allowance (max. per tip)	0.81 mm (.032")
Contact Opening (nominal)	10.44mm (.411")
Contact Forced (each tip)	5.7 kg (12.51 lbs.)

ARCING CONTACTS

Contact Wear Allowance (each tip)	3.96mm (.156")
Contact Opening (nominal)	7.62mm (.300")
Contact Force (nominal)	6.8 kg (14.9 lbs.)

INTERLOCK CONTACTS

A-B, C-D Contacts	Normally Open
E-F, G-H Contacts	Normally Closed
Contacts Opening	4.8mm(3/16")
Contact Lift	2.39mm (.094")
Contact Wear Allowance (max. per tip)	0.25mm (.010")

MAIN MAGNET COIL

Rating, Continuous	9 VDC
Rating, Intermittent	74 VDC
Resistance at 20 Degrees C (68 Degrees F), 10%	1.95 OHMS

PILOT COIL

Rating, Continuous	74 VDC
Resistance at 20 Degrees C (68 Degrees F), 10%	140 OHMS

OPERATION

Working Voltage, Continuous	74 VDC
Pickup at 20 Degrees C (69 Degrees F), Max	48 VDC
Dropout at 20 Degrees C (68 Degrees F)	5 to 25 VDC

HI-POT..... 60 Hz, 1 Minute

CAUTION Hi-pot values above 5400 volts are not recommended.

Magnet Coil To Mounting	600 V RMS
Magnet Coil To Main Contacts	
Main Contact To Mounting	
Main Contacts To Interlock Contacts	5400 V RMS
Between Open Main Contacts	
Interlock Contacts To Mounting	
Interlock To Interlock	

MATERIAL LIST

Loctite Retaining Compound	
Movable Main Contact Support Locknut	Grade A-A
Arc Tip Lever Shoulder Screw	Grade 271
Movable Arc Tip To Arc Tip Lever	Grade 222
Loctite Cleaner-Activator, 6 oz. aerosol can	8352873
Silicone Rubber Compound (RTV), 5 oz. tube	8453256

SPECIAL TOOL

Extraction Tool (Lead Removal From Terminal Socket)	Amp. Inc. 458994-1
---	--------------------

Document Number MM001088

Electro-Motive Division Of General Motors Corporation
La Grange, Illinois 60525 USA
Telephone: 708-387-6000

©Copyright 1990 Electro-Motive Division, General Motors Corporation. All rights reserved. Neither this document, nor any part thereof, may be reprinted without the expressed written consent of the General Motors Locomotive Group. Contact EMD Customer Publications Office.